



Parts List for DCG414B Type 1

Item Number	Part Number	Description	Qty Required
1	N426540	HOUSING ASSEMBLY	1
2	N480240	GEARCASE ASSY	1
3	N115381	CLAMP WASHER	1
4	N484249	FLANGED HEX NUT	1
5	N508174	MODULE & STATOR ASSY	1
6	N495932	ROTOR ASSY.	1
7	N455878	GEARCASE COVER ASSY.	1
8	N071836	ROLL PIN	1
9	N461411	PINION	1
10	N465886	PAWL SPRING	1
11	N372039	NUT	1
12	N442976	LEVER	1
13	N412210	SCREW	4
14	N042665	MACHINE SCREW	2
15	330019-04	SCREW,PLASTITE	7
16	N436965	COVER,VENT	2
17	N297219	SHOULDER SCREW	1
18	330045-06	SCREW	5
19	330021-11	STOP NUT	2
20	N091479	MOUNT- SPRING	1
21	N438439	HANDLE INSERT	1
22	N438438	HANDLE INSERT	1
23	330019-03	SCREW,PLASTITE	1
24	N467560	PLATE	1
25	N461735	SPRING	1
90	N383283	SIDE HANDLE	1
91	N107295	HEX WRENCH	1

Parts List for DCG414B Type 1

Item Number	Part Number	Description	Qty Required
94	N441218	GUARD	1
95	N409059	GUARD	1
101	N452803	RATING LABEL	1
102	N472969	WARNING LABEL	1
103	N456217	LABEL	1
104	N456227	LABEL	1
105	N456230	LABEL	1
106	N456231	LABEL	1
107	N450663	LABEL	1
800	30301914-01	GREASE	1
836	5140229-19	MAGNETIC POLE VIEWER	1
846	N545570	SILICONE SEALANT	1
856	N311419	GUARD	1
856	N409540	GUARD	1
856	562086-10	GRINDING WHEEL	1
862	629053-00	TOOL BAG	1
866	DCB606	FLEXVOLT BATTERY	1
867	N475920	BATTERY CAP	1
871	DCB118	CHARGER	1